METREL[®] **Electrical Installation Safety** SINGLE-FUNCTIONAL TESTERS

MI 3123 SMAR EC[®] Earth / Clamp

The MI 3123 SMARTEC Earth / Clamp is a new generation earth resistance tester with the ability to perform 4-wire earth resistance measurement and 4-wire specific earth resistance measurement. With the optional A 1019 current clamps the instrument can perform 4-wire earth resistance measurement with one current clamp, contactless earth resist-ance testing with two clamps and TRMS current measurement up to 20 A. Configurable limits enable a PASS / FAIL evaluance example net two composition in the current interparement up to 20 K. Configurable limits enable a PASY FAIL evalu-ation of test results. All the results can be saved on the instrument and then downloaded via the optional software for evaluation and professional report generation after testing. The lightweight design, large bright LCD screen, built-in help screens, optional downloading via R5232 or USB ports and overvoltage category CAT IV make the MI 3123 an incredible earth resistance measuring instrument.

MEASURING FUNCTIONS:

- Earth resistance, 4-wire method;
 Earth resistance, 4-wire method with
- one current clamp (option); Earth resistance, two clamps method
- (option);
- (option);
 Specific earth resistance;
 TRMS current (option).

KEY FEATURES:

- KEY TEATUKES:
 Earth resistance measurement: in-strument performs standard 4-wire earth resistance tests with two earth-ing rods and specific earth resistance measurement.
 Selective earth resistance test: op-tional 4-wire earth resistance measure-ment in combination with an additional current clamp is used for measuring earth resistance of individual earthing rods. ods
- Contactless earth resistance test: Contactless earth resistance test: earth resistance measurement with 2 current clamps without breaking the loop is intended for measuring resistance of individual earthing rods and is reccomended first of all for urban ar-ease
- recommended first of all for urban ar-eas. Downloadable: downloads via R5232 or USB cable directly to the PC with the help of the optional software. Upgradeable: if changes occur to the regulations upgrades can be made to the firmware to keep the instrument up to date. Help screens: instrument comes for re-leta with built in help screens for ref.
- plete with built-in help screens for ref-
- encina on site
- Built-in charger & rechargeable bat-teries: instrument has a built-in charg-





ing circuit and comes complete with a set of rechargeable NiMH batteries. • Custom limits: the limits can be set on any function, in that case large green and red lights of the LEDs will indicate a PASS or FAIL evaluation of test result

• Easy to use: large bright LCD display and large buttons enable easy handling of the instrument (even while wearing aloves).

• Magnetic holder: magnet for fixing instrument on metal surfaces enables hands-free operation.

APPLICATION:

Testing on TT and IT systems;
Testing sub-station earthing;
Lightning system testing.

STANDARDS:

Functionality: IEC/EN 61557 Other reference standards for testing: IEC/EN/HD 60364; AS/NZ 3018; CEI 64.8; HD 384; BS 7671; VDE 0413 Beck, ND 384, BS 7071, VDE 0413 Electromagnetic compatibility: IEC/EN 61326-1; IEC/EN 61326-2-2 Safety: IEC/EN 61010-1; IEC/EN 61010-031; IEC/EN 61010-2-032

Accessories: page 1.60

Electrical Installation Safety SINGLE-FUNCTIONAL TESTERS

TECHNICAL DATA:

| Function | Measuring range | Resolution | Accuracy |
|---|---|--|---|
| Earth resistance (4-wire method (EN 61557-5); 4-wire method with one cur- rent clamp) | 0.00 Ω 19.99 Ω 20.0 Ω 199.9 Ω 200 Ω 1999 Ω 2000 Ω 9999 Ω | 0.01 Ω 0.1 Ω 1 Ω 1 Ω | ±(3 % of reading + 3 digits) ±(3 % of reading + 3 digits) ±5 % of reading ±10 % of reading |
| Earth resistance (2 clamps method) | 0.00 Ω 19.99 Ω 20.0 Ω 30.0 Ω 30.1 Ω 99.9 Ω | 0.01 Ω 0.1 Ω 0.1 Ω | ±(10 % of reading + 10 digits) ±20 % of reading ±30 % of reading |
| Specific earth resistance (EN 61557-5) | 0.0 Ωm 99.9 Ωm 100 Ωm 999 Ωm 1.00 kΩm 9.99 kΩm 10.0 kΩm 99.9 kΩm >100 kΩm | 0.1 Ωm 1 Ωm 0.01 kΩm 0.1 kΩm 1 kΩm | Calculated value, consider earth resist- ance 4-wire method |
| TRMS Current | 0.0 mA 99.9 mA 100 mA 999 mA 1.00 A 19.99 A | 0.1 mA 1 mA 0.01 A | ±(3 % of reading + 3 digits) |
| Power supply | 6 x 1.2 V rechargeable batteries, type AA | | |
| Overvoltage category | CAT IV / 50 V | | |
| Protection class | Double insulation | | |
| COM port | RS232 and USB | | |
| Dimensions | 140 x 230 x 80 mm | | |
| Weight | 0.85 kg | | |

KEY FEATURES







USB and RS232 communication ports.

Large LCD screen with backlight and PASS / Simple and fast manipulation. FAIL indicators.

STANDARD SET:

Instrument Smartec Earth / Clamp
 Soft hand strap
 Tost lead, A5 m (blue)
 Tost lead, A5 m (bred)
 Tost lead, 20 m (green)
 Tost lead, 20 m (green)
 Tost lead, 20 m (black)
 Earth test rod, 4 pcs
 Power supply adapter + 6 NiMH recharge-able batteries, type AA
 Instruction manual on CD

Short instruction manual
Handbook on CD
Calibration certificate

Accessories: page 1.60

1.43

METREL®